



Pelagic Sailing Club

Satisfaction Shut Down List

1. Store all cockpit gear in proper location in the Cabin.
(VHF Radio, GPS, Winch Handles, etc.)
2. Store all Cockpit Cushions on Pilot Berth.
3. Shut Engine and Galley Sink Through Hulls.
4. Shut Head Sink Drain and Fill Sink with Fresh Water.
(About 1/2 gallon)
5. Pump out Head until Dry (Leave Fresh Water in Head Drain Hose.
6. Shut Head Overboard Discharge Valve.
7. Check that all Portlights and Hatches are closed
8. Shut off Inverter Inverter and Main DC inverter Switch
9. Shut off all D/C circuit breakers
10. Shut off Main Battery Switch.

If Ice Box is Left on, replace orders on 8, 9 & 10 above with 8, 9 & 10 below:

8. Leave master DC Circuit Breaker on Panel on.
9. Leave Refrigerator Circuit Breaker on.
10. Leave Main Battery Switch on.

Continue Shut Down Procedure Below:

11. Remove Speed Sensor if used with Blank Plug (making sure it is screwed tight under Wood Cover on Deck in V-Berth)
12. Check that all seacocks are closed including Holding Tank Pump Out Valve under Port Side V-Berth
13. Lock Cockpit Lazerette Cover
14. Place Wash Boards in and Lock Boat (9260)